Assembly&instruction Manual

SPU: SPC000269







165.35inch X 118.11inch X 75.98inch camping tent

Thank you very much for choosing **cobizi's** camping tents, after opening the box, please check the following accessories to see if they have their full, any problems with the product, please contact our service email!


Team mailbox: **service@cobiziofficial.com**

Have a nice trip !


Part & Accessories

No	A	B	C	D	E	F	G	H	I	J	K
List	Long frame tube A 	Short fram tube B 	Steel Pole C 	Rope 	Steel peg 	Tent 	Rain Fly 	Bag 	Steel pole 	Steel pole with Two pins 	Steel pole with One pins 
Qty	2 PCS	1 PCS	4 PCS	8 PCS	14 PCS	1 PCS	1 PCS	1PCS	2 PCS	2 PCS	2PCS


SET UP




Assemble the tent poles.




Put the tent poles(A)into the body of the tent through the sleeves ,forming an "X" shape over the tent.And connect the pole to the Hub (11mm hole).




Thread the pole (B) through the pipe cloth and secure it with copper buckles at both ends.




Connect the four steel poles (C)to the Hub (19mm hole) in sequence.




Insert the single rod into the steel pole one by one.



Insert the steel pole(J) to the plastic connector



Put the outer tent on top of the inner tent and connect it with an “S”hook.



Tie out the rain fly sides using the webbing loops, fix the guy lines with tent peg.

Made in China

Warning: To avoid the potential dangers of suffocation , please keep all parts and packaging away from babies and children .