COBIZI

CONTACT US:

If you have any questions about the installation of COBIZI products, just e-mail us at service@cobiziofficial.com

Alternative method to contact us (amazon.com orders only)

1.Log into your Amazon account


2.Go to “Your Orders” and find the purchase

3.Click on “Contact Seller”

MAKING THE BEST OUTDOOR FURNITURE FOR YOU.

COBIZI

ASSEMBLY INSTRUCTION



20X50 FT PARTY TENT

Product comes packaged in 4 boxes that might not arrive together; Safety measures and professional installation are highly recommended.
Before returning to the store,please contact our Customer Service

service@cobiziofficial.com


We appreciate the trust and confidence you have placed in COBIZI through the purchase of our product. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.
Thank you for choosing COBIZI.

Made in China


COBIZI

MAKING THE BEST OUTDOOR FURNITURE FOR YOU.


1. Before commencing assembly, make sure to gather all the necessary parts and arrange them systematically.
2. Under no circumstances should candles, matches, or any open flames be used inside or in close proximity to the tent.
3.If any part of the pipe is deformed during transportation, you can use pliers to restore the shape of the pipe.

Item no.	Reference Image	Qty.
1	 ϕ38*2000mm	X21
2	 ϕ38*1930mm	X16
3	 ϕ38*1080mm	X16
4	 ϕ38*1910mm	X16
5	 ϕ25*1925mm	X12
A		X2
A1		X4
B		X6
B1		X12
C		X16
D		X24

11








To improve wind resistance,
be sure to complete this installation step. If expansion screws or ground nails are not installed,strong winds may topple the gazebo.
Expansion screws are essential for stability on cement surfaces, and ground nails are for grassy surfaces.
Ground nails are included in the package while expansion screws are not provided.




Installation Completed


COBIZI MAKING THE BEST OUTDOOR FURNITURE FOR YOU.


Item no.	Reference Image	Qty.
E	 M6X55mm	X16
F	 M6X25mm	X24
G		X8
H		X106
I		X1
W1		X2
W2		X2
W3		X2
M		X2
N		X40
O		X32
P		X14

1












COBIZI MAKING THE BEST OUTDOOR FURNITURE FOR YOU.

10







9



Ⓗ16pcs



W1 2pcs



W2 2pcs





W3 2pcs



Ⓜ2pcs

The fasteners marked in red are the same ones used in step 4.
4 bungee cord fasteners are needed for part 3 (marked in blue).
Hang SIDE WALL W1,W2 and W3 from left to right, the other side is the same.





15

COBIZI MAKING THE BEST OUTDOOR FURNITURE FOR YOU.


2




②16pcs




Ⓓ16pcs




③16pcs






5




6


3

⑤8pcs Ⓕ16pcs Ⓟ14pcs






7





8




8

Ⓒ16pcs M6X55mm Ⓔ16pcs







14


7




⑤4pcs





ⒹⒹ6pcs






12





13

4




Ⓘ1pc



ⒽⒽ82pcs

4 and 8 bungee cord fasteners are used for parts 1,2 and 4 to temporarily secure. These same fasteners are used to secure the cloth during step 9.







9

5

④8pcs







10

COBIZI MAKING THE BEST OUTDOOR FURNITURE FOR YOU.

6

④8pcs





11